




RAIZER® Quick Guide

AUS Version 1.3



1



Approach to the fallen person

2




Place the seat on the floor by the person's side.

Lift the thighs to an angled position.

Carefully push the seat in under the thighs.

3



Turn the person's shoulder by a careful push of the elbow.

Carefully push the back rest (marked red for left-hand side) in under the person's shoulder.


4



Slide the back rest in and click into place in the seat.

If necessary, place a foot in front of the seat to prevent it from moving forward.

Push the rear leg (marked red for left-hand side) onto the shaft and click into place.




Slide the front leg (marked red for left-hand side) into the seat and click it into place.




Repeat.
Green mark = right hand side



Control panel



9



Support the person's neck with one hand. Press the "up arrow" on the side panel or remote control (Supplementary equipment).

! Please note: Risk of being pinched

10



The Raizer® will automatically stop when the person is in a sitting position.

11



Run the Raizer® into a horizontal position and disassemble.



Sprinkling prohibited



#1: 9 kg.
#2: 4 kg.



Max. User weight



40 - 100 transfers pro charge